

Cerberus NetSTATS

SNMP Configuration Guide - Netgear

The following details the steps you need to make your router ready for use with the Cerberus NetSTATS broadband monitoring service.

It is recommended that you connect your computer directly to the device to make the configuration changes. This may require you to change the IP address of your computer to be able to contact the router on its management IP. Please review configuration support documentation for your own operating system on how to do this.

Once connected to the router follow the steps below.

1. Access the router web interface visiting the following URL <http://192.168.0.1/snmp.htm> in your web browser.
2. Tick the box **Turn SNMP On** to enable this feature. Enter the *SNMP Read Community String* in the field labelled **Read Community Name**.

SNMP

Turn SNMP On

Read Community Name

System Contact

System Name

System Location

3. Once you have entered the details click on the apply button.
4. Configuration is now complete. You can now close your web browser.

Should you have any queries on how to carry out these procedures, please contact our support team on 0845 257 1335 or via email at support@cerberusnetworks.co.uk.